



- NOTE-**
- 1) ALL WELDS SHOULD BE GROUND AND POLISHED SMOOTH TO A #3 (150 GRIT) FINISH.
 - 2) ALL ROUGH EDGES SHOULD BE CLEANED OF ANY BURR'S.
 - 3) ALL ANGLES ARE AT 90° UNLESS OTHERWISE NOTED.
 - 4) ALL RADIUS AND CORNERS ARE TO BE A 1/32 UNLESS OTHERWISE NOTED.

LEGEND

WORKING SPACE (DO NOT BLOCK)

THIS DRAWING AND ANY ATTACHMENTS TO THIS DRAWING ARE CONFIDENTIAL AND PRIVILEGED INFORMATION, AND ARE THE SOLE PROPERTY OF LANCE JACOBS, AND WAGNER PACKAGING MACHINERY, PLANO-TX

REVISIONS			
REV	DESCRIPTION	DATE	BY

APPROVED BY: _____
 DATE: _____
 SIGNATURE: _____

PROJECT	WAGNER PACKAGING MACHINERY
ADDRESS	2904 DARTMOUTH DR. PLANO, TEXAS 75075
PHONE	PHONE: 972-385-8456 FAX: 972-499-1898
WWW	WWW.WAGNERPKG.ORG LANCE@WAGNERPKG.ORG
SCALE	WAGNER PACKAGING MACHINERY RESERVES PROPRIETARY RIGHTS TO THIS DRAWING AND THE DATA SHOWN THEREON. THIS DRAWING AND DATA ARE PROPERTY AND ARE NOT TO BE USED OR REPRODUCED FOR ANY PURPOSE WITHOUT THE WRITTEN CONSENT OF WAGNER PACKAGING MACHINERY.
DRAWN BY	Lance J
DATE	
CHECKED BY	
DATE	
REV	Wagner Pkg - LJ
TYP	DWG
REV	REV 1
DATE	REV 0